



PARTS LIST

No.	Parts No.	Description	Q'ty
1	7712G-01	Handle	1
5	7712G-05	Pin	1
6	7712G-06	Housing Lock Ring	1
7	7712G-07	Trigger	1
8	7712G-08	Pin	1
9	7712G-09	O-Ring	1
10	7712G-10	Regulator	1
11	7712G-11	Valve Stem	1
12	7712G-12	O-Ring	2
13	7712G-13	Valve Ball	1
14	7712G-14	Spring	1
15	7712G-15	Inlet Bushing	1
41	7712G-41	Ball Bearing	2
42	7712G-42	Rear End Plate	1

No.	Parts No.	Description	Q'ty
43	7712G-43	Cylinder	1
44	7712G-44	Rotor Blade	4
45	7712G-45	Rotor	1
46	7712G-46	Bushing	1
47	7712G-47	Front End Plate	1
48	7712G-48	Cylinder Housing	1
49	7712G-49	Adaptor	1
50	7712G-50	Holding Tool	1
51	7712G-51	Backing 3" Plate	1
52	7712G-52	Backing 4-1/2" Plate	1
53	7712G-53	Backing 5-1/2" Plate	1
54	7712G-54	Adaptor Lock Down	1
64	7712G-64	6" Wheel Guard	1
65	7712G-65	Screw	1

ST-7712G-P-0506B-LW