



PARTS LIST

No.	Parts No.	Descri tion	Q't
1C	6660-01C	Housing Assembly [Incl. 1-1, 1-2, 1-3, 1-4, 12]	1
1-1	6660-01-1	Reverse Valve Bushin	1
1-2	6660-01-2	Reverse Valve Bushin Gea	1
1-3	6660-01-3	Heli-Coil	4
1-4	6660-01-4	Set Scre	1
2	6660-02	Trigger Assembly [Incl. 2B-1, 2B-2]	1
2B-1	6660-02B-1	Tri er Pin	1
2B-2	6660-02B-2	Tri e	1
3	6660-03	Throttle Valve Assembly [Incl. 3A-1, 3A-2]	1
3A-1	6660-03A-1	Throttle Valve Pin	1
3A-2	6660-03A-2	Throttle Valve	1
5	6660-05	Throttle Valve Sea	1
5	6660-05	O-Rin	1
06	6660-06	S rin	1
07	6660-07	Exhaust Deflecto	1
08	6660-08	ir Inle	1
09	6660-09	Housin Plate	1
10	6660-10	Gaske	1
11	6660-11	Screw	2
12	6660-12	Grease Fittin	1
13	6660-13	Reverse Valve	1
14	6660-14	O-Rin	2
15	6660-15	Reverse Valve Knob	1
16	6660-16	Screw	1
17	6660-17	Retaine	1
18	6660-18	Ball Bearin	1
19	6660-19	Rear End Plate Assembly [Incl. 18	1

No.	Parts No.	Descri tion	Q't
20	6660-20	Gaske	1
21	6660-21	Roto	1
22	6660-22	Rotor Blade	6
23	6660-23	C linde	1
24	6660-24	C linder Dowel	1
25	6660-25	Front End Plate Assembly [Incl. 27]	1
26	6660-26	Pin	1
27	6660-27	Ball Bearin	1
28	6660-28	Motor Clam Washe	2
29	6660-29	Se arato	1
30	6660-30	Gaske	1
31	6660-31	Hammer Case	1
32	6660-32	Bushin	1
33	6660-33	Screw	4
34	6660-34	S rin Washe	4
35	6660-35	Washe	1
36	6660-36	Hammer Frame	1
37	6660-37	Hammer Pin	2
38	6660-38	Hamme	2
39	6660-39	Standard Anvil Incl. 40, 41	1
39B	6660-39B	6" Extended Anvil (Select) [Incl. 40, 41]	1
40	6660-40	Socket Retaine	1
41	6660-41	O-Rin	1
42	6660-42	Steel Ball	1
43	6660-43	S rin	1
46B	6660-46B	Handle O tion	1
TK	6660-TK	Tune-Up Kit [Incl. 5A, 6, 14(2), 17, 18, 20, 22(6), 27, 30, 40, 41, 42, 43]	