



PARTS LIST

No.	Parts No.	Description	Q'ty
1B	5548-01B	Housing Assembly [Incl. 8, 9, 10, 46A(3), 48]	1
2A	5548-02A	Throttle Valve Seat	1
3B	5548-03B	Throttle Valve Assembly [Incl. 3B-1, 3B-2]	1
4	5548-04	Spring	1
5A	5548-05A	Exhaust Deflector	1
6	5548-06	Air Inlet	1
7	5548-07	Muffler Element	1
11	5548-11	O-Ring	1
12	5548-12	Reverse Valve	1
13	5548-13	O-Ring	1
14	5548-14	Spring	2
15	5548-15	Steel Ball	2
16	5548-16	Reverse Valve Knob	1
17	5548-17	Screw	2
18	5548-18	Retainer	1
20A	5548-20A	O-Ring	1
21A	5548-21A	Trigger Assembly [Incl. 19]	1
	-	o or	
23	5548-23	Ball Bearing	1
24	5548-24	Ball Bearing	1
25	5548-25	Retainer	1

No.	Parts No.	Description	Q'ty
26	5548-26	Cylinder	1
27	5548-27	Cylinder Dowel	1
29	5548-29	Rotor Blade	6
30	5548-30	Front End Plate	1
31	5548-31	Rear End Plate	1
32	5548-32	Gasket	1
33	5548-33	Motor Clamp Washer	2
34	5548-34	Hammer Frame	1
35	5548-35	Hammer Pin	2
37	5548-37	Hammer	2
38	5548-38	Hammer Case	1
38A	5548-38A	Separator	1
39	5548-39	Gasket	1
40	5548-40	Bushing	1
41	5548-41	Screw	3
43A	5548-43A	Standard Anvil [Incl. 44, 45]	1
43B	5548-43B	2" Extended Anvil (Select) [Incl. 44, 45]	1
44	5548-44	Socket Retainer	1
45	5548-45	O-Ring	1
TK	5548-TK	Tune-Up Kit [Incl. 4, 7, 9, 11, 13, 14(2), 15(2), 20A, 23, 24, 25, 29(6), 32, 39, 44, 45]	

ST-5548-P-1210F-01